

FC-*i* series FC-*Si* series

INSTRUCTION MANUAL

Counting Scale



FC-50 <i>Ki</i>	FC-5000 <i>Si</i>
FC-20 <i>Ki</i>	FC-500 <i>Si</i>
FC-10 <i>Ki</i>	
FC-5000 <i>i</i>	
FC-2000 <i>i</i>	
FC-1000 <i>i</i>	
FC-500 <i>i</i>	

A&D

A&D Company, Limited

This manual and Marks

All safety messages are identified by the following, "WARNING" or "CAUTION", of ANSI Z535.4 (American National Standard Institute: Product Safety Signs and Labels). The meanings are as follows:

 WARNING	A potentially hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	A potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



This is a hazard alert mark.



This mark informs you about the operation of the product.



The information mark of other operations.

Note This manual is subject to change without notice at any time to improve the product. No part of this manual may be photocopied, reproduced, or translated into another language without the prior written consent of the A&D Company.

Product specifications are subject to change without any obligation on the part of the manufacture.

Compliance with FCC rules

Please note that this equipment generates, uses and can radiate radio frequency energy. This equipment has been tested and has been found to comply with the limits of a Class A computing device pursuant to Subpart J of Part 15 of FCC rules. These rules are designed to provide reasonable protection against interference when this equipment is operated in a commercial environment. If this unit is operated in a residential area it might cause some interference and under these circumstances the user would be required to take, at his own expense, whatever measures are necessary to eliminate the interference. (FCC = Federal Communications Commission in the U.S.A.)

Copyright©2003 A&D Company, Limited

Contents

1. INTRODUCTION	3
1-1. Introduction.....	3
1-2. Unpacking	4
1-3. Setting Up Your Scale	5
1-4. Standby and Operating Mode.....	7
1-5. Simple Operation Mode.....	7
1-6. kg or lb Weighing Units	7
1-7. Last Unit Weight Used Feature	8
2. FRONT PANEL OVERVIEW	9
3. BASIC OPERATIONS	10
3-1. Basic Operations.....	10
3-2. To Start Counting.....	12
3-3. Unit Weight By Samples.....	13
3-4. Unit Weight By KEYBOARD.....	17
3-5. Unit Weight By ID Number	18
4. ENTERING A TARE WEIGHT	19
4-1. Using the KEYBOARD TARE Key.....	19
4-2. To Clear TARE.....	20
5. STORE UNIT WEIGHT	21
5-1. Store Unit Weight by ID Number	21
5-2. Clearing A Stored Unit Weight	22
5-3. Store Item Code by ID Number	23
5-4. Unit Weight, Tare, Comparator Limits & Total Count Stored	25
6. USING THE M+ MEMORY	26
6-1. The M+ Memory Function	26
6-2. Viewing the M+ Total	27
6-3. Clearing the M+ Total	27
6-4. The M- Function	27
7. COMPARATOR FUNCTION.....	28
8. TIME AND DATE FUNCTION.....	30
9. CALIBRATION	31

9-1.	Calibration Procedure Using a Weight	31
9-2.	Gravity Compensation.....	33
10.	F-FUNCTION PARAMETERS.....	34
10-1.	To Change or View F-Function Settings.....	34
10-2.	F-Functions	36
11.	ACAI FUNCTION	44
11-1.	ACAI Automatic Counting Accuracy Improvement	44
11-2.	ACAI Automatic Operation	44
11-3.	ACAI Manual Operation	45
12.	RS-232C SERIAL INTERFACE	46
12-1.	RS-232C Specifications	46
12-2.	Data Output Mode.....	47
12-3.	Connecting the AD-8121 Printer / MODE 1 or MODE 2.....	48
12-4.	Connecting the AD-8121 Printer / MODE 3.....	49
12-5.	Command Mode	50
12-6.	Using a Bar Code Reader.....	55
12-7.	Using UFC (Universal Flex Coms) Function	59
13.	OPTIONS	62
13-1.	OP-01 Bar Code Reader.....	62
13-2.	OP-02 Ni-MH Battery Pack	65
13-3.	OP-03 2 Ch. RS-232C	67
13-4.	OP-04 RS-232C and Comparator Relay Output	68
13-5.	OP-05 Remote Scale Interface	69
14.	SPECIFICATIONS	73
14-1.	Dimensions	75
15.	GRAVITY ACCELERATION MAP.....	76
16.	INDEX	78

1. INTRODUCTION

1-1. Introduction

Thank you for your Purchase!

This manual describes the functions of your counting scale and how to get the most out of it. Read this manual carefully before use.

Features

The FC-*i* / FC-*Si* counting scales have the following features:


- £ The scales have the following high internal resolution for a wider range of counting applications.
 - £ FC-*i* counting scale: 1/1,000,000
 - £ FC-*Si* counting scale: Up to 1/10,000,000
- £ There are the following ways to enter a unit weight (of the sample piece).
 - £ The way to weigh a fixed number of samples like 5 pieces, 10 pieces and so on.
 - £ The way to weigh the desired number of samples.
 - £ The way to store the desired unit weight directly using the 10-key pad.
 - £ The way to recall the stored unit weight from ID memory.
 - £ The way to send the desired unit weight from a personal computer.
 - £ The way to use a bar code reader to designate an ID number to enter the unit weight directly.
- £ Three UNIT WEIGHT BY LED's will navigate you to store a unit weight easily.
- £ ACAI (Automatic Counting Accuracy Improvement) supports counting by recalculating the unit weight when a sample is added. Therefore it is possible to reduce the counting error.
- £ The scale has a large bright vacuum fluorescent display and can show information for piece count, weight, unit weight, ID number, item code and comparator result at the same time.
- £ UP to 500 ID memories can store 6 digits ID numbers, consisting of 12 digit item code (alphanumeric), unit weight, tare weight and comparator limits.
- £ Comparator function:
 - £ Compare a count or weight
 - £ Comparator limits can be changed temporarily using the 10-key pad.
 - £ Comparator relay output is also available using an optional interface.
- £ Accumulation function for counting.
- £ Standard RS-232C interface and optional interfaces (up to 3 ch. RS-232C available) to communicate with a personal computer, printer and bar code reader expanding the counting application.
- £ A two-scale counting system can be constructed using the optional a remote scale interface and remote platform.

- £ It is possible to send the time and date to a computer connected to the RS-232C interface using the scale's built-in clock.
- £ The optional rechargeable battery pack (Ni-MH) is useful for portable operation.



1-2. Unpacking

- £ Unpack the scale carefully and keep the packing material if you are likely to transport the scale again in the future.
- £ In the carton you should find this manual plus:
 - £ The counting scale.
 - £ An AC adapter (check that the AC input rating is correct).


Remove the protective packing materials from around the scale and between the pan and scale casing.



Instruction Manual




AC Adapter
Please confirm that the AC adapter type is correct for your local voltage and receptacle type.




FC-1000i
FC-500i

How to assemble the breeze break (Only for FC-500Si)
Assemble the breeze break as shown below. Follow the numbered sequence.



FC-500Si




Breeze ring
Only for FC-5000Si

FC-5000Si


1-3. Setting Up Your Scale

1. Place the scale on a suitable weighing surface (Refer to **Best Conditions For Weighing** of next page) and turn the adjustable feet until the spirit level shows that the scale is level.



2. Plug in the AC adapter. The AC input requirements could be 100, 120, 220, 230 or 240 Volts (50/60Hz) depending on where used, so, please check that the adapter is correct. Ground the scale to avoid a problem with the static electricity.
- £ The display comes ON
After running through a self-check that will show various segments, the weighing display will appear.

1111111 à à 9999999 à à - - - - - à à
self-check waiting for weighing data to become stable



3. Please leave the scale with the AC adapter connected for at least thirty minutes before use. We call this situation "warm up".
If desired: press the **STANDBY/OPERATE** key to turn the display off.
Remember that the scale will always be warmed up as long as the AC adapter is connected. This keeps the scale always ready for use.

Best Conditions For Weighing

- £ The scale must be level (check the spirit level on the scale).

- £ Best operating temperature is between 20°C~25°C / 68°F~77°F at about 50%~60% relative humidity. There shouldn't be large temperature fluctuations.
- £ The weighing room should be kept clean and dry.
- £ The weighing table must be of a solid construction.
- £ Corners of rooms are best as they are less prone to vibrations.
- £ Don't install the scale near heaters or air conditioners.
- £ Don't install the scale in direct sunshine.
- £ Try to ensure a stable AC power supply when using the AC adapter.
- £ Keep equipment containing magnets away from the scale.
- £ Warm up the scale before use or leave it on standby overnight.
- £ Ground the scale chassis for electrostatic discharge if the weighing conditions warrant.

Calibration

Calibration of the scale is required when the scale is initially installed, or if a remote scale is added. Please refer to “**9. CALIBRATION**” for more calibration information.

1-4. Standby and Operating Mode



The scale has two principal modes: Standby mode and operating mode.

Standby mode: When the scale has power supplied to it, either by the AC Adapter or the battery pack, and the display shows a decimal point, the scale is in the standby mode. In day-to-day operation, standby mode is normal when the scale is not in use. This keeps the weighing mechanism warmed up.

Operating mode: If the display is turned on from standby mode, then the scale is in operating mode.

If the scale is not going to be used for a long period of time, then it may be appropriate to disconnect the main power.


- £ Use the **STANDBY/OPERATE** key to turn the display on or off. When the scale is in Standby mode, a period appears in the weight display as an indicator.



1-5. Simple Operation Mode

If desired, the scale can be set in a simple operation mode. In this mode, only front panel keys that would be used in "3-3. Unit Weight By Samples" counting operations are active. All others will not operate. The following keys are active in the simple operation mode:

Keys that will operate in simple operation mode:




1-6. kg or lb Weighing Units

USA Version ONLY

The scale can weigh and register the unit weight in pounds or kilograms (it comes set to pounds "lb"). When you switch between the weighing units, the display will show the current weighing unit, and any weight amounts being used are also converted.

- £ To change the weighing units between pounds and kilograms, refer to F-Function f-00-01. Set at "0" for kg; or at "1" for lb.




1-7. Last Unit Weight Used Feature



There are a number of ways to register a unit weight to count. The scale has a feature to keep the last unit weight used in memory. This can be handy if you turn the scale display off and then want to return to the same unit weight, or you accidentally clear the unit weight by pressing the **RESET** key.

When a unit weight is registered it is automatically placed in the ID "i d-000000" and remains there until a new unit weight is entered, or the power is disconnected. It can be recalled by the following:



1. When three **UNIT WEIGHT BY** LED's are blinking at display ON, or if the **RESET** key has been pressed;



2. Press the **ID** key.
"i d-000000" will be displayed with \ddot{e} 000000 \grave{i} blinking.



3. Press the **ENTER** key.
The scale will recall the previous unit weight.



Automatic Last Unit Weight Used

When you turn the display on, the scale can automatically recall the last unit weight used from memory, if desired.

- £ Set the F-Function f-01-04 at "1". The scale will recall the last unit weight used, when the display is turned ON.

2. Front Panel Overview

The diagram shows the front panel of a scale with various indicators and buttons. The main display shows '1620' and '123456'. The keypad includes buttons for PRINT, REMOTE SCALE, TOTAL, RESET, and a numeric keypad. A simplified operation section shows buttons for ID, SAMPLE, KEYBOARD, STORE UNIT WEIGHT, and ENTER.

SCALE
 1: main scale is used.
 2: remote scale is used.

The **TOTAL** indicator comes on when the count display is showing the total.

The **ZERO** indicator comes on when the scale is at the center of zero.

The **M+** indicator comes on when count data is being accumulated.

The **PRINT** key sends count, weight or unit weight data.

The **REMOTE SCALE** key switches between the main and a remote scale (if used).

The **TOTAL** key displays the accumulated data on the count display and also back again.

The **PRINT** key sends count, weight or unit weight data.

The **RESET** key clears the Unit Weight data in memory (but not in ID memory).

The **[0] ~ [9]** & **[.]** 10-keys send numbers to the display.

The **[C]** key clears the display 10-key input.

The **[SAMPLE]** key is used when entering sample size.

The **[KEYBOARD]** key is used when unit weight is to be entered via the 10-key.

The **[ID]** key is used when recalling unit weight data from ID memory.

The **[ENTER]** key enters unit weight, sample size, ID or other data into the scale from the 10-key pad.

The **[STORE UNIT WEIGHT]** key stores the unit weight on display, item code data to ID memory.

The **[ID]** number display (6 digit).

Item code stored in the ID memory (12 digit).

The **SCALE** indicator comes on when the tare weight is subtracted.

The **STABLE** indicator comes on when the weighing data is stable.

Count (pcs) display.

Comparator results.

Weight display

The **' ACAL** indicator comes on when weight is within the ACAL range. When meeting the ACAL addition range, it will blink.

The **' SAMPLE TOO LIGHT** indicator comes on when the unit weight is too light.

Unit weight display.

The **STANDBY/OPERATE** key turns the display on and off.

The **[ZERO]** key returns the scale to the center of zero.

The **[KEYBOARD TARE]** key allows entering a known tare weight from the 10-key pad.

The **[TARE]** key subtracts the tare weight.

The **[ZERO]** key subtracts the tare weight.

The **[STORE UNIT WEIGHT]** key stores the unit weight on display, item code data to ID memory.

The **[ID]** number display (6 digit).

Item code stored in the ID memory (12 digit).

The **[ENTER]** key enters unit weight, sample size, ID or other data into the scale from the 10-key pad.



The **[STORE UNIT WEIGHT]** key stores the unit weight on display, item code data to ID memory.

3. BASIC OPERATIONS

3-1. Basic Operations

Turn The Display ON and OFF


1. Press the **STANDBY/OPERATE** key to turn the scale on when displaying the standby indicator. The display will show all the display segments first and show “-----” while the weighing data becomes stable.




2. The scale will automatically assume zero (power-on zero) and the display will show zero.



- £ The range for power-on zero is $\pm 10\%$ of the weighing capacity around the calibrated zero point.



- £ If there is something more than 10% of the capacity on the weighing pan, the display will show “err 1”. Remove everything from the weighing pan or press the **RESET** key. When you press the **RESET** key, the power-on zero doesn't work.



3. Press the **STANDBY/OPERATE** key again, and the scale returns to the standby mode.


ZERO

- £ The **ZERO** key will bring the weight display back to zero as long as the weighing pan is empty or within 2% of capacity.

1. Remove everything from the weighing pan and press the **ZERO** key. Then the display shows “-----” and waits for the weighing data to become stable.

2. The scale will zero and the ZERO indicator will come on to indicate that the scale is ready to start weighing or counting.


- £ There is an automatic zeroing function called “zero tracking”. The scale initially comes with this function enabled to take care of normal zero drift caused by changes in temperature, humidity, air pressure etc. (F-Function f-04-01).





TARE

£ The **TARE** key will subtract the displayed container weight.

1. Remove everything from the weighing pan and press the **ZERO** key to zero the scale.




2. Place a tare container on the weighing pan. The weight display will show the weight of the container.



Container weight

3. Press **TARE** key. Then the display shows "-----" and waits for the weighing data to become stable.




4. The scale will subtract the weight of the container and the weight display changes to net weight.



£ The TARE ENTERED indicator will be displayed.


3-2. To Start Counting

1. Press the **STANDBY/OPERATE** key to turn the scale on when displaying the standby indicator. Or press the **RESET** key to clear any previous operations.



2. Three LED's on the **UNIT WEIGHT BY** keys will blink. This is to prompt you to select a method for entering a unit weight for operation.

3. select one of the ways to enter or recall the unit weight (the weight of one item of what you are counting), and refer to the section noted for more instructions.




You can return to this point at any time during operation by pressing the **RESET** key. (This doesn't clear the entered tare weight and M+ memory.)





3-3. Unit Weight By Samples

10 Sample Size

- Three **UNIT WEIGHT BY** LED's should be blinking at this point, if not, press the **RESET** key to clear any unit weight. If you are going to use a tare container, place it on the weighing pan.





- Press the **SAMPLE** key. Any tare container will be automatically tared. The display will show "5XX GUad`Y" and "10 pcs".





⚠ If weight isn't zero, press the TARE.

- Place 10 sample pieces on the weighing pan (or in the tared container). The weight of all 10 pieces will be displayed.




- Press the **ENTER** key. The display will show "-----" for a moment while calculating the unit weight. After a moment the display will show the count, total weight and unit weight.

ë Blinking



⚠ At this point the scale may decide that 10 pieces is not a large enough sample size for accurate counting. If you refer to the "5XX GUad`Y" display again, then add the additional number of sample pieces displayed.




- You can ignore the "5XX GUad`Y" message and continue counting by pressing the **ENTER** key. However, the results may not be accurate. Refer to F-Function f-01-02.

Total Weight
The weight of all the sample pieces

Unit Weight
The calculated weight of a unit.

- You may now begin counting operations for pieces of the same weight.




- Please refer to "11. ACAI FUNCTION" for information concerning the ACAI counting accuracy function.



Another 24 pieces.

5, 25, 50 or 100 Sample Size

- Three **UNIT WEIGHT BY** LED's should be blinking at this point, if not, press the **RESET** key to clear any unit weight. If you are going to use a tare container, place it on the weighing pan.





- Press the **SAMPLE** key. Any tare container will be automatically tared. The display will show "5XX GUad`Y" and "10 pcs".





⚠ If weight isn't zero, press TARE.

- Press the **SAMPLE** key to move through the count number of 5, 25, 50 or 100 pieces.




- £ The larger the sample size used, the more accurate the unit weight will be registered. (Example of selecting a sample size of 50)


- Place the selected number of sample pieces on the weighing pan (or in the tared container). The weight of the pieces will be displayed.




è Blinking



- Press the **ENTER** key. The display will show "-----" for a moment while calculating the unit weight. After a moment the display will show the count, total weight and unit weight.




⚠ If the "5XX GUad`Y" display appears again, then the sample size is not large enough for accurate counting – add the additional number of sample pieces.





- You may now begin counting operations for pieces of the same weight.

Desired Sample Size

- Three **UNIT WEIGHT BY** LED's should be blinking at this point, if not, press the **RESET** key to clear any unit weight. If you are going to use a tare container, place it on the weighing pan.





- Press the **SAMPLE** key. Any tare container will be automatically tared. The display will show "5XX·GUad`Y" and "10 pcs".





⚠ If weight isn't zero, press TARE.

- Use the **0** à **9** 10-key pad to display the sample size desired.





- £ If you hit the wrong key, press the **C** key to clear and start again. (Example of selecting a sample size of 20)

- Place the selected number of sample pieces on the weighing pan (or in the tared container). The weight of the pieces will be displayed.




- Press the **ENTER** key. The display will show "-----" for a moment while calculating the unit weight. After a moment the display will show the count, total weight and unit weight.

è Blinking





⚠ If the "5XX·GUad`Y" display appears again, then the sample size is not large enough for accurate counting – add the additional number of sample pieces.



- You may now begin counting operations for pieces of the same weight.



Desired Sample Size Not Using The **[SAMPLE]** Key

- Three **UNIT WEIGHT BY** LED's should be blinking at this point, if not, press the **[RESET]** key to clear any unit weight. If you are going to use a tare container, place it on the weighing pan and press the **[TARE]** key. Be sure the weight display is "0".





⚠ If weight isn't zero, press the TARE.

- Place sample pieces on the weighing pan (or in the tared container). The weight of the pieces will be displayed.





- Use the **[0]** à **[9]** 10-key pad to enter the sample size of the pieces you placed. If you hit the wrong key, press the **[C]** key to clear and enter again. (Example of setting a sample size of 20)




- Press the **[ENTER]** key. The display will show dashes for a moment while calculating the unit weight. After a moment the display will show the count, total weight and unit weight.

è Blinking




⚠ If the "Add Sample" displays again, then the sample size is not enough for accurate counting - add the additional number of sample pieces.





- You may now begin counting operations for pieces of the same weight.

3-4. Unit Weight By KEYBOARD





- Three **UNIT WEIGHT BY** LED's should be blinking at this point, if not, press the **RESET** key to clear any unit weight. If you are going to use a tare container, place it on the weighing pan and press the **TARE** key to tare the container.



- Press the **KEYBOARD** key. The unit weight display and the **ENTER** key LED will blink.



- Use the **0** à **9** and **.** 10-key pad to display the unit weight.
- If you hit the wrong key, press the **C** key to clear and start again. (Example of a unit weight 32g)




- Press the **ENTER** key. The unit weight 32g will have been entered.



⚠ If the unit weight entered is too light, "l o ut" (low unit weight) will be displayed, and you will be returned to step 3.

- You may now begin counting operations for pieces of the same weight.





3-5. Unit Weight By ID Number

1. If there are no unit weight's stored in memory, refer to "5-1. Store Unit Weight by ID Number".



Three **UNIT WEIGHT BY** LED's should be blinking at this point, if not, press the **RESET** key to clear any unit weight.

2. Press the **ID** key.
"i d-000000" will be displayed with $\dot{\text{i d-000000}}$ blinking.





- £ If you have been using the unit weight by ID number, its ID number stays displayed and blinks.

3. Use the **0** à **9** 10-key pad to display the ID number.




- £ If you hit the wrong key, press the **C** key to clear and start again. (Example of ID number "123456")

4. Press the **ENTER** key.
The count display will show "0" and the scale will recall "12g" previously entered as the unit weight of ID 123456.



- ⚠ If there is no unit weight entered for the ID number you tried to recall, "no i d" will be displayed, and you will be returned to step 3.



5. You may now begin counting operations for pieces of the same weight.

i £ "i d-00000" is a special memory area. It always holds the last Unit Weight entered.

£ When you register a unit weight , it is automatically placed in the ID "i d-00000".

£ If you clear the unit weight by pressing the **RESET** key, it can be recalled by recalling the ID "i d-00000".

4. ENTERING A TARE WEIGHT


There are two methods of tare operations.

- £ Using the **TARE** key to subtract the displayed container weight directly. Please refer to “3-1. Basic Operations”.
- £ Using the **KEYBOARD TARE** key to enter a tare weight via the 10-key pad.

4-1. Using the KEYBOARD TARE Key



1. Remove everything from the weighing pan and press the **ZERO** key to zero the scale.

2. Press the **KEYBOARD TARE** key.
The weight display will blink (display is any tare weight previously entered).





3. Use the **0** à **9** and **.** 10-key pad to display the desired TARE weight.

£ If you hit the wrong key, press the **C** key to clear and start again. (Example of a tare weight 615g)



4. Press the **ENTER** key.
The weight display changes to net weight.


£ The **TARE ENTERED** indicator will light.




4-2. To Clear TARE

Either:

1. Have nothing on the weighing pan.
 If the ZERO indicator is not displayed, press the **ZERO** key to zero the scale.




2. Press the **TARE** key.
 The weight display will go to "0", and the TARE ENTERED indicator will be turned off (tare cleared).





Or:



1. Press the **KEYBOARD TARE** key.
 The weight display will blink (display is any tare weight previously entered).



2. Press the **0** key and press the **ENTER** key.



3. The tare weight is cleared and the TARE ENTERED indicator will be turned off.



5. STORE UNIT WEIGHT

5-1. Store Unit Weight by ID Number

The scale can store up to 500 unit weights by 6 digit ID numbers, from 000001 to 999999. To recall, refer to “3-5. Unit Weight by ID Number”.


£ The scale is initially set to store the ID numbers with a unit weight and an item code only. However, it can be set to store a tare weight, comparator limits and total count by setting F-Function f-01-05.

1. First register a unit weight by any method – using a sample or via the 10-key pad – and have it displayed.



2. Press the **STORE UNIT WEIGHT** key. “i d-000000” will appear with 000000 blinking.



£ If you have been using the unit weight by ID number, its ID number stays displayed and blinks.



3. Use the **0** à **9** 10-key pad to display the new ID number.



(Example of ID number “123456”)

£ If you hit the wrong key, press the **C** key to clear and start again.





4. Press the **ENTER** key.

The ID number is stored and the display returns to normal.




⚠ If the same ID number was previously stored, the scale beeps twice and the ID number display blinks. i d-123456i

You must then select one of two options: either (a) Overwrite the old ID unit weight, or (b) Select a different ID number:




OR




5-2. Clearing A Stored Unit Weight

1. Press and hold the **C** key, then press the **STORE UNIT WEIGHT** key – release both.




2. “7`YUf`=8” will appear and “id-000000” will appear with 000000i blinking.



3. Use the **0** à **9** 10-key pad to display the ID number to clear.



(Example of ID number “123456”)

- £ If you hit the wrong key, press the **C** key to clear and start again.




4. Press the **ENTER** key.

After showing “id-----” for a moment, the ID number will be cleared and the display returns to normal.





- ⚠ If there is no such ID number to clear, the scale will beep. Return to step 3 to try again, or press the **RESET** key to exit.



Clearing All ID Memories at Once


1. In the step 2 above, press the **TOTAL** key. “id-all” will appear with all i blinking.



2. Press the **ENTER** key, then ẽ all i blinking will stop.




3. Press the **ENTER** key again to clear all of ID memories. Press the **RESET** to exit without clearing ID memories. The display will return to normal.





5-3. Store Item Code by ID Number

An item code of up to 12 alphanumeric characters can be set using the 10-key pad, and it will be stored with the ID number.


1. Press the **STORE UNIT WEIGHT** key. "i d-000000" will appear with `000000` blinking.



2. Enter the ID number desired using the `0` à `9` 10-key pad.



3. Press the **STORE UNIT WEIGHT** key again. The symbol "5" with blinking cursor `5` will appear.



- £ To return to step 2, press the **STORE UNIT WEIGHT** key.

- ⚠ To select the symbol "5", "U" or "%", press the **M+** (A/a) key.

This shows which type of character will be entered.
 5: Capital letter
 U: Lowercase letter
 %: Numeric character

Cursor can be moved using `←` and `→` keys.

Example of entering "A&D Co., Ltd.": Select the symbol "5" first.

4. Press the `2` (ABC) key to place "5".
5. Press the `0` (#) key several times to place "/".
6. Press the `3` (DEF) key to place "8".
7. Press the **TOTAL** (`↵`) key twice to shift the cursor.
8. Press the `2` (ABC) key several times to place "7".
9. Press the **M+** (A/a) key to change the symbol "5" to "U".
10. Press the `6` (MNO) key several times to place "c".

"5" 5

"5" 5 /

"5" 5 / 8

"5" 5 / 8 S

"5" 5 / 8 7



"U" 5 / 8 S

"U" 5 / 8 7c

"U" 5 / 8 7c " z @ h X

- £ Repeat these procedures to the last letter.


11. Press the **ENTER** key.
The ID number is stored with Item code and the display returns to normal.




- £ You may return to step 2 by pressing the **STORE UNIT WEIGHT** key.

⚠ If the same ID number was previously stored, the scale beeps twice.


You must then select one of two options:
either (a) Overwrite the old ID unit weight, or
(b) Select a different ID number:





(a) Press the **ENTER** key to overwrite the old ID number.

OR



(b) Press the **C** key to clear and retype the new ID number.

Alphanumeric Character Table

Key	Capital Letters	Lowercase Letters	Numeric Characters
1	4 · O · Q · R · S ·		% ·
2	5 · 6 · 7 ·	U · V · W	& ·
3	8 · 9 · : ·	X · Y · Z ·	' ·
4	; · < · = ·	[· \ ·] ·	(·
5	> · ? · @ ·	^ · _ · ` ·) ·
6	A · B · C ·	a · b · c ·	* ·
7	D · E · F · G ·	d · e · f · g ·	+ ·
8	H · I · J ·	h · i · j ·	, ·
9	K · L · M · N ·	k · l · m · n ·	- ·
0	· ~ · ı · / · ¢ · fl · L · l · Ž · ž ·		\$ ·
.	! · " · # · ° · ¢ · , · / · 0 · 1 · 2 · 3 ·		" ·
C	Clear (Space)		

STORE UNIT WEIGHT : ID number input ß à Item code input

PRINT ß : To shift the cursor left


TOTAL à : To shift the cursor right


M+ A/a : Capitalà Lowercaseà Numericà Capitalà ...

5-4. Unit Weight, Tare, Comparator Limits & Total Count Stored

The scale is initially set to store the ID numbers with a unit weight and an item code only. However, it can be set to store a tare weight, comparator limits and/or total count also by setting F-Function f-01-05.

1. First register a unit weight and a tare weight by any method. If necessary, set the comparator limits and use the M+ accumulation.
2. Go to step 2 of section “5-1. Store Unit Weight By ID Numbers”.



 When you recall a unit weight by the **ID** key, the tare, comparator limits and/or total count are also recalled along with the unit weight.



“i d-00000”, the special memory area, does not store a tare weight, comparator limits and total count along with unit weight.

6. USING THE M+ MEMORY


6-1. The M+ Memory Function


- £ The scale can accumulate count data by pressing the **M+** key, or automatically (refer to the next page). It also keeps track of the number of times you add to the total.
- £ When you view the total by pressing the **TOTAL** key, you view the number of pieces accumulated and the number of additions (how many times the total was added to). Please refer to “6-2.” and “6-3.” to view or clear the total count.




Adding Using the M+ Key

£ When stable count data is displayed:

1. Press the **M+** key.
The **M+** indicator will blink for a few seconds.

 If the scale beeps 4 times, or the **M+** indicator did not blink, then refer to the note below.

 The **M+** indicator will stay ON while there is count in memory.



2. Press the **M+** key every time you want to add to the count. Remember that you may only add the count data once – the scale must return to near zero before it will let you add again.

£ The **M+** key is accepted only once for every stable count data. Once accepted, the **M+** key is prohibited until the display returns to less than +5d (1d = 1 weighing division).


£ If f-03-02 is set at “1”, then the **M+** key can accumulate negative data. Once the **M+** key is accepted, weight data must return within $\pm 5d$ before the next accumulation.

£ To store the total count in the ID number, refer to “5-4. Unit Weight, Tare, Comparator Limits & Total Count Stored”.


£ The total count is not stored in the ID memories automatically even if it was recalled by ID number.

To Erase the Last M+ Addition

1. Press and hold the **C** key, then press the **M+** key – release.





2. The scale will clear the last **M+** addition.


 If the scale beeps 4 times, there is no **M+** addition to erase.

Automatic **M+** Accumulation Mode

£ **M+** Accumulation can also be done automatically each time you count a different batch, As soon as you have a stable count, it will be added to the **M+** memory and the scale will beep«. The weight display will have to return to near zero before another count can be added.

 Automatic **M+** accumulation is set by F-Function f-03-01 at "1".


 Only positive counts can be added. If F-Function f-03-02 is set at "1" (to accept negative count data), it will be ignored.

 Once there is an automatic **M+** accumulation, the display must return to less than +5d before another count can be accumulated.

6-2. Viewing the **M+** Total


1. Press the **TOTAL** key.
The count display will show the total count and the) **TOTAL** indicator will come ON.
The number of additions to the **M+** memory is also shown.

2. Press the **TOTAL** key again.
The display will return to normal.



6-3. Clearing the **M+** Total

1. Press and hold the **C** key, then press the **TOTAL** key – release both.



2. The scale will clear the **M+** memory, and the) **TOTAL** indicator and the) **M+** indicator will go OFF.



£ The **RESET** key does not clear the total data.

£ The total data is held in memory, but if AC/Battery power to scale is interrupted, the total data will be lost.

6-4. The **M-** Function

£ The scale can subtract count data from **M+** memory by using the ***** key.

£ Set the F-Function f-09-01="1" to use the ***** key as **M-** key.



This function is not to clear the last **M+** addition, but to subtract count data instead of addition. The number of additions is increased.

 There is no automatic **M-** function.

7. COMPARATOR FUNCTION

£ The scale contains a comparator function that checks the amount on the weighing pan against set acceptable count or weight levels. When the comparator function is activated, “<=”, “C?” or “@C” is displayed.

£ Before the comparator will work, upper and lower limits must be set (refer to below). The levels are set by count or weight. So, if you are using weight for your comparator levels, calculate the weight before starting the procedure below.


£ If OP-04 is installed, comparator relay output is also available.

£ The comparator responds as follows,

“<=” Upper limits < Count / Weight data

“; C” Lower limits Ω Count / Weight data Ω Upper limits

“@C” Count / Weight data < Lower limits



«ë beep, beep ...ì«

Upper limit 102 pcs


Lower limit 98 pcs

The beeper is set ON at


To Set the Comparator

£ Start with the scale in standby mode, display OFF.



1. Press and hold the **ZERO** key, then press the **STANDBY/OPERATE** key – release both.




The count display will show “f-00” with “00” blinking.



2. Press the **5** key to enter into the F-Function **f-05-X Comparator**.



3. Press the **ENTER** key.






The count display will show the F-Function and its present setting will blink.

- Use the **0** à **6** keys to display the number of the desired setting.


For example, let's select "1" compare all data.

- Press the **ENTER** key to save the setting and move to next F-Function, f-05-02.

- Continue to enter f-05 comparator settings – refer to "10-2. F-Functions" for a listing. If there are no changes to a F-Function, press the **ENTER** key to move to the next.



- When finished: press the **STANDBY/OPERATE** key to exit. Then, press it to turn the display back ON. Comparator functions will now operate as set.





**To ENTER
or
MOVE to next**

Viewing Comparator Limits

- £ The comparator limits you are using will be shown by pressing the ***** key.
- £ Set f-09-01="0" to use this mode.

- Press the ***** key, then upper and lower limits will be shown.
- Press the ***** key twice, the display will return to normal.





Upper limit Lower limit

Changing Comparator Limits Temporarily


- £ Set f-09-01="0" to use this mode.

- In step 1 above, press the **ENTER** key, the upper limit value will blink.
- Change the upper limit using the 10-key pad and press the **ENTER** key. The upper limit will stop blinking and the lower limit blinks.



- Change the lower limit using the 10-key pad and press the **ENTER** key. Then the display will return to normal with the new limits.



 These temporary limits will disappear when the display is turned off.

8. TIME AND DATE FUNCTION


£ The scale has a time and date function and that data can be sent through the RS-232C interface. There are two ways to set time and date.

To Set in the F-Function Settings


£ Start with the scale in standby mode, with the display is turned off.

1. Press and hold the **ZERO** key, then press the **STANDBY/OPERATE** key – release both to enter the F-Function setting mode. The count display will show “f-00” with “00” blinking.


2. Key in **1 1** and press the **ENTER** key to display the setting value, time and date. If you want to change the order of year, month and date, use the **0** à **2** to change the setting.



3. Press the **C**. The first digit of time and date will blink. Use the 10-key pad to set the time and date.



 The "seconds" value is fixed to "00".




4. Press the **ENTER** key to return to the step 2 and the clock will start from “00” seconds.
5. Press the **STANDBY/OPERATE** key to exit, and press it again to turn the display back ON.



Using the ***** Key to Set the Time and Date

£ Set the F-Function f-09-01="0" to use the ***** key as this function.


1. Press the ***** key twice to display the time and date.



2. Press the **ENTER** key, then the first digit of date will blink.



3. Use the 10-key pad to set the date and press the **ENTER** key. Then the first digit of time will blink.



 The “seconds” value is fixed to “00”.



- Use the 10-key pad to set the time and press the **ENTER** key to return to normal. The clock will start from "00" seconds.

9. CALIBRATION

£ Calibration of the scale is required when it is initially installed, if it is moved often, or it is moved a substantial distance. Calibration is also necessary in regular scale maintenance due to normal mechanical wear-and-tear, changes in seasonal temperature, humidity, air pressure, etc.



⚠ The scale is equipped with gravity compensation, which allows it to be calibrated in one location and then adjusted to match the gravity acceleration at another location where it will be used. But don't worry about this, as far as you calibrate the scale using a calibration weight and use it at same place.

⚠ The scale must perform "warm up" (with the AC adapter connected) for at least 30 minutes before starting calibration.

9-1. Calibration Procedure Using a Weight

⚠ The scale should have power connected at least one-half hour to warm it up before starting the calibration procedure.

- Remove the calibration switch cover, and press the calibration (CAL) switch. The scale shows "Cal" in the count display.



£ Press the CAL switch to exit without calibrating the scale.

- Press the **ZERO** key to enter into zero & span calibration mode.

£ The display flashes the required calibration weight value.




⚠ If you know the exact weight value, or if you wish to use a different weight, use the **0** à **9** and **.** 10-key pad to





display the desired calibration weight.
 (For example: Using 10kg calibration weight
 that actually weighs 10.002kg.)

- Press the **ENTER** key.
 The calibration weight stops blinking
 and “Cal 0” appears.




- Making sure that there is nothing on, or touching
 the weighing pan, press the **ENTER** key.
 When zero calibration is completed, the display
 will show “Cal f”.





-  If you don't need span calibration, press the
 CAL switch to exit from the calibration
 procedure.



- Place the calibration weight on the weighing pan
 and press the **ENTER** key.
 When span calibration is completed, the display
 will show “7U`] Vf Uh] cb` 9bX”.



-  If the calibration weight is not what it should be,
 an error will be displayed. Check if the weight is
 correct and try again.



- Press the **CAL** switch and re-attach the
 calibration switch cover.
 (End of the calibration procedure.)



If the scale will be moved to another place, set the gravity
 acceleration value before calibration. The value must be of the
 area where the calibration is to be done.


9-2. Gravity Compensation

⚠ When the scale is first used or has been moved to different place, it should be calibrated using a calibration weight.


But if the calibration weight cannot be prepared, the gravity acceleration correction will compensate the scale. Change the gravity acceleration value of the scale to the value of the area where it will be used. Refer to the gravity acceleration map appended to the end of this manual.

1. In step 1 of the previous procedure, press the **TARE** key.



The display flashes the gravity acceleration value stored in the scale.



2. Use the **0** à **9** and **.** 10-key pad to display the desired gravity acceleration value. (Example of the value 9.800 m/s².)



3. Press the **ENTER** key. The scale will store the new value. If necessary to calibrate the scale using a weight, go to step 2 of the previous section.



4. Press the **CAL** switch and re-attach the calibration switch cover. (End of the calibration procedure.)



10. F-FUNCTION PARAMETERS

10-1. To Change or View F-Function Settings

£ Start with the scale in standby mode, with the display is turned off.


1. Press and hold the **ZERO** key, then press the **STANDBY/OPERATE** key.

The count display will show "f-00" with "00" blinking. Then release the both keys.




2. Press the **0** à **9** keys to display the number of the F-Function.

£ For example: the **5** key to enter into the F-Function **f-05-X Comparator**.



3. Press the **ENTER** key.
The count display will show the F-Function and its present setting will blink.

4. You may now either change the setting (step 5) or move to the next F-Function (step 6).




5. Use the **0** à **9** keys to change the setting.



⚠ The **C** key clears the input setting if you press the wrong key and want to re-enter.

⚠ If you make a mistake and want to escape without saving any changes made after the last time the **ENTER** key was pressed – press the **STANDBY/OPERATE** key to exit.


⚠ After the **ENTER** key is pressed, the data is entered.



6. Press the **ENTER** key to save any changes and/or move to the next item.



7. When finished: Press the **STANDBY/OPERATE** key to exit. Then, press it to turn the display back on. The new settings will operate as set.



10-2. F-Functions

£ “ ” designates factory settings.

F-00-X Weighing Unit

USA Version ONLY

f-00-01	£ Weight Display.	
	0	kg (kilograms, FC- <i>i</i> series), g (grams, FC- <i>Si</i> series)
	1 [~]	lb (pounds).

f-00-02	£ Unit Weight (when “lb” is selected).	
	0	lb as piece weight.
	1 [~]	lb as 1,000 piece weight.

F-01-X Operations

f-01-01	£ Operation Mode.	
	0 [~]	Normal operation. All features and keys available.
	1	Simplified operation. The unit weight registration is by sample only. All other keys are disabled.

f-01-02	£ “Add” Sample Request Override. If the sample weight is too light and the scale asks to “Add” more sample pieces, using this F-Function, the unit weight can be entered without adding the requested sample pieces. Or disable the “Add” sample request function.	
	0	“Add” sample request function is disabled. Light unit weight can be accepted without “Add” more sample request.
	1 [~]	The unit weight <u>can be entered</u> without requested “Add” sample pieces (via the ENTER key).
	2	The unit weight <u>cannot be entered</u> without requested “Add” sample pieces (via the ENTER key).

f-01-03	£ Auto REMOTE SCALE After Unit Weight Registration. The scale can be set to the remote scale after the unit weight registration, instead of having to manually press the REMOTE SCALE key. Please note that this does not affect any other use of the REMOTE SCALE key.	
	0 [~]	No automatic switching.
	1	Automatic switching to the remote scale.
	2	Automatic switching to the main scale.

*F-01-03 requires
OP-05 and a
remote scale*

f-01-04

£ Display ON Unit Weight – Reset or Last. When the display is turned on, the scale can be set to recall the last unit weight used.	
0~	The unit weight is RESET (cleared) when display comes on.
1	The unit weight last used (before display is turned off, not power interrupt) will be entered automatically.

f-01-05

£ ID Memory Contents. The scale ID memory can contain unit weights with tare weights, comparator limits and total count, or just unit weights alone. Item codes are always contained.																						
000~	ID memory contains the unit weight and item code only.																					
<table border="0"><tr><td>TOTAL</td><td>TARE</td><td></td></tr><tr><td>count</td><td>Weight</td><td></td></tr><tr><td>↓</td><td>↓</td><td></td></tr><tr><td colspan="3">000</td></tr><tr><td></td><td></td><td>↑</td></tr><tr><td></td><td></td><td>Comparator</td></tr><tr><td></td><td></td><td>limits</td></tr></table>	TOTAL	TARE		count	Weight		↓	↓		000					↑			Comparator			limits	You select which data to be stored by keying in a <input type="text" value="0"/> or <input type="text" value="1"/> for the data: tare weight, comparator limits or total count. <i>Example:</i> Key in <input type="text" value="0"/> <input type="text" value="1"/> <input type="text" value="0"/> to display 010, ID memory contains the unit weight including item code and comparator limits.
TOTAL	TARE																					
count	Weight																					
↓	↓																					
000																						
		↑																				
		Comparator																				
		limits																				

f-01-06

F-01-06 requires OP-05 and a remote scale

£ Unit Weight With A 2 Scale System. When operating a 2 scale system, the remote scale may have an independent unit weight, or restricted to the same as the main scale.	
0	Each scale can have its own unit weight.
1~	Main and remote scales have the same unit weight only.

F-02-X ACAI Operation & Min. Unit Weight

f-02-01	£ ACAI Mode When Unit Weight Entered by <i>Sample Pieces</i>.	
	0	ACAI is disabled.
	1 [~]	ACAI automatic operation.
	2	ACAI manual mode (using the ENTER key).

f-02-02	£ ACAI Mode When Unit Weight Entered by <i>Keyboard or ID</i>	
	0	ACAI is disabled.
	1 [~]	ACAI manual mode (using the ENTER key). This setting works when f-02-01 setting is not "0".
	2	ACAI automatic obeys f-02-01 setting.

f-02-03	£ Minimum Unit Weight. (1d=1 weighing display division) The factory setting may be different for some countries.	
	0	1/5 d (FC- <i>i</i> series), 1/20 d (FC- <i>Si</i> series)
	1 [~]	1/100 d (FC- <i>i</i> series), 1/400 d (FC- <i>Si</i> series)

F-03-X M+ Accumulation Function

f-03-01	£ M+ Accumulation – Automatic or Manual	
	0 [~]	Manual accumulation (by pressing the M+ key).
	1	Automatic accumulation (Positive data only).



f-03-02	£ + or – Count Data Acceptable. (Manual Accumulation)	
	0 [~]	Positive data only (5d and above).
	1	Positive and negative data (5d and above or –5d or below).
	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>f-03-02=0</p> </div> <div style="text-align: center;"> <p>f-03-02=1</p> </div> </div>	

F-04-X Environment and Beeper

f-04-01	£ Zero Tracking. Zero tracking traces a drift from zero caused by temperature changes etc., and stabilizes the zero point.	
	0~	Zero tracking ON.
	1	Zero tracking OFF.
f-04-02	£ Response	
	0	Fast / sensitive
	1~	Normal
	2	Slow / stable
f-04-03	£ Stable Detection Speed / Environment	
	0	Fast stable detection (good environment).
	1~	Normal.
	2	Slow stable detection (poor environment).
f-04-04	£ Beeper for key operation	
	0~	Beeper ON.
	1	Beeper OFF.

F-05-X Comparator

f-05-01	£ Comparator Mode.	
	0~	comparator off.
	1	compare all data.
	2	compare stable data.
	3	compare all data except when near zero*.
	4	compare stable data except when near zero*.
	5	compare all positive data except when near zero*
	6	compare stable positive data except when near zero*.
	* "near zero" means between -4d and +4d of weight data.	
f-05-02	£ Data to Compare – Count or Weight	
	0~	Compare count data.
	1	Compare weight data.

f-05-03	£ Upper Limit.	
	0 [~]	Enter via the 10-key pad. Use the <input type="text" value="-"/> or <input type="text" value="."/> key to "set minus value."
f-05-04	£ Lower Limit.	
	0 [~]	Enter via the 10-key pad. Use the <input type="text" value="-"/> or <input type="text" value="."/> key to set minus value.
f-05-05	£ A Beeper With Comparator Results. These are beeps for the comparator, not for the key operation.	
	000 [~]	All Comparator Beepers are OFF.
		<p>Example: </p> <p>0 = Beeper OFF 1 = Beeper ON</p> <p>The OK beep sounds – HI & LO doesn't sound. The scale will beep continuously when display meets OK condition.</p>
f-05-06	£ Factory Use.	
	0 [~]	This setting should be "0".

F-06-X/F-07-X/F-08-X Data Output

f-06-X for standard RS-232C,
f-07-X for Ch.1 (PORT 1) and
f-08-X for Ch.2 (PORT 2).

f-⁰⁶₀₇-01	£ Data Out Mode	
	0 [~]	Key mode: Data is sent by pressing the <input type="text" value="PRINT"/> key. + command mode.
	1	Stream mode: Data is sent continuously. command mode cannot be used.
	2	Auto-print mode A: Data is sent if the weight display is stable at +5d (weighing display division) and above. + command mode.
	3	Auto-print mode B: Data is sent if the weight display is stable, at ±5d (weighing display division) and above/below. + command mode
	4	Command mode only.
	5	To use as Bar Code Reader Interface.
	6	UFC format with Key Mode (see setting "0").
	7	UFC format with Auto-Print Mode A (see setting "2").
	8	UFC format with Auto-Print Mode B (see setting "3").

⁰⁶
f-⁰⁷-02
₀₈

£ Data to be Sent.	
00100~	Count data sent.
<p>Date/Time ID Unit Weight</p> <p>↓ ↓ ↓ ↓</p> <p>00000</p> <p>↑ ↑</p> <p>PCS(count) Weight</p>	<p>You select which data to be sent by keying in a <input type="checkbox"/> 0 or <input type="checkbox"/> 1 for the data: Date, ID no., PCS (count), weight or unit weight.</p> <p><i>Example:</i> Key in <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 0 to display 01100, this setting would send only the ID number and the count.</p>

⁰⁶
f-⁰⁷-03
₀₈

£ Data Format		
0~	Format for AD-8121 MODE 1.	No difference between "0" and "1" when used with the UFC format.
1	Format for AD-8121 MODE 3.	
2	Format for general apparatuses, computers, etc.	

⁰⁶
f-⁰⁷-04
₀₈

£ Baud Rate	
0~	2400 bps.
1	4800 bps.
2	9600 bps.

⁰⁶
f-⁰⁷-05
₀₈


£ Data Length and Parity	
0~	7 bits, even parity.
1	7 bits, odd parity.
2	8 bits, non parity.

F-09-X * key

f-09-01	£ Operation mode for the * key	
	0	Operating as a MODE key to display comparator upper and lower limits, and time and date.
	1	Operating as M- key to subtract Count data from M+ memory.

f-09-02	£ Decimal Point and Weight Data for RS-232C Output	
	0	Decimal point="." Stable weight data format ="ST,+001.23456 kg"
	1	Decimal point = "," Stable weight data format = "ST,+001,2346 kg"
	2	Decimal point = "." Stable weight data format = "WT,+001.2346 kg"
	3	Decimal point = "," Stable weight data format = "WT,+001,2346 kg"

F-10-X External Control Signal Input

f-10-01	f-10-02	£ Control Signal Input #1 and #2.	
		<p>Select an input (key function) as listed below for each Functions f-10-01 and f-10-02. Prepare a 3.5mm stereo jack plug and connect one or two switches to this.</p> 	
	0	Reset RESET . (Factory Setting for f-10-01)	
	1	Enter ENTER . (Factory Setting for f-10-02)	
	2	Tare TARE .	
	3	Zero ZERO .	
	4	Sample SAMPLE .	
	5	Remote Scale REMOTE SCALE .	
	6	Total TOTAL .	
	7	M+ M+ .	
	8	Standby / Operate STANDBY/OPERATE .	
	9	Print PRINT .	

F-11-X Time & Date

f-11-01


£ Time and Date Display. Select the order of date display.	
0	Year-Month-Date.
1	Month-Date-Year.
2	Date-Month-Year.

11. ACAI FUNCTION

11-1. ACAI Automatic Counting Accuracy Improvement

The ACAI™ (Automatic Counting Accuracy Improvement) function recalculates the unit weight as more pieces are added to improve count accuracy.

When the scale calculates the unit weight from sample pieces, the more sample pieces that are used, the higher the accuracy.




ACAI Notes



- £ You must do the ACAI procedure just after you set the unit weight. The samples must be still on the weighing pan.
- £ Do not take the samples off until the end of the ACAI procedure.
- £ You don't have to count out the pieces when you add, just stay within the ACAI range.
- £ Continue the ACAI procedure to reach the largest amount that you will be counting.
- £ If you want the most precise counting results for every different batch of the same items, use ACAI every time you start counting the next batch.
- £ The ACAI does not work when you use a remote scale if the unit weight was set on the main scale and vice versa.
- £ The ACAI function is initially set to manual operation when the unit weight is set digitally by the keyboard, by ID memory or using computer via the serial interface. This can be set to the automatic mode. The ACAI mode when the unit weight is entered by ID or digital input is controlled by F-Function f-02-02. It is initially set at "0", ACAI manual operation mode. Set to "1" for automatic operation mode.

11-2. ACAI Automatic Operation


1. To start ACAI automatic operation, the unit weight must be registered and the samples still on the weighing pan.




2. Add pieces within the nearest ACAI range (refer to table below). A good rule of thumb is to roughly double the amount on the weighing pan.




Pcs On the Weighing Pan	ACAI Addition Range		
10	13~27	60	63~123
20	23~50	70	73~139
30	33~71	80	83~153
40	43~90	90	93~167
50	53~107	100	103~300
		over 200	203~493



As you add, the ACAI indicator will be ON as long as you are in range.



When you stop adding and the display becomes STABLE, the ACAI indicator will blink.




After the new unit weight is calculated, the indicator will disappear,

- Continue adding pieces within the ACAI range until you have reached a sample size as large as the largest number of pieces that you will be counting.
- £ When you have added the maximum number of pieces required, remove the sample pieces and start your counting job.

11-3. ACAI Manual Operation

- £ The ACAI procedure can also be controlled manually. The ACAI will not recalculate the unit weight until the **ENTER** key is pressed (as long as it is at the proper time and the guidelines in the ACAI notes have been followed).
- £ The ACAI manual mode is controlled by F-Function f-02-01, set at "2".
- £ To start ACAI manual operation, the unit weight must be registered and the samples still on the weighing pan.

- Add pieces within the nearest ACAI range (refer to table in the previous section). The ACAI indicator will stay ON as long as you are within the ACAI range.




- Wait until the display becomes stable and press the **ENTER** key. When the new unit weight is calculated, the indicator will blink for a moment and disappear.
 - Continue adding pieces within the ACAI range until you have reached a sample size as large as the largest number of pieces that you will be counting.
- £ When you have added the maximum number of pieces required, remove the sample pieces and start your counting job.

12. RS-232C SERIAL INTERFACE


- £ The scale has not only a standard RS-232C interface but also optional interfaces, Ch.1 and Ch.2.
- £ The specifications described in this section are common to all of the RS-232C interfaces.

12-1. RS-232C Specifications

Transmission system	EIA RS-232C
Transmission form	Asynchronous, bi-directional, half-duplex
Data format	Baud rate: 2400, 4800, 9600 bps
	Data: 7 bits + parity 1bit (even or odd) or 8 bits (non-parity)
	Start bit: 1 bit
	Stop bit: 1 bit
	Code: ASCII
	Terminator: Data Send / C _R L _F (C _R : 0Dh, L _F : 0Ah) Data Receive / C _R or C _R L _F



Pin connections




- £ The scales are designated as DCE (Data Communication Equipment).

12-2. Data Output Mode

- £ The data output modes and parameters are set by F-Functions in f-06 / 07 / 08-X as described in the F-Function parameters, section 9.
- £ To control the scale using commands from an external device, refer to “12-5. Command Mode”.
- £ Refer to “12-5. Command Mode” about the output data format.

Data Out Mode (f-06/07/08-01)


- £ Key Mode (f-06/07/08-01="0")
When the weight display is stable, data is sent by pressing the **PRINT** key.
The count display will blink when the data has been sent.
- £ Stream Mode (f-06/07/08-01="1")
Data is sent continuously. The data-update rate is approximately 5 times per second for f-06/07/08-03="2". For f-06/07/08-3="0" or "1", the interval between continuous data is approximately 2 seconds.
- £ Auto-print Mode A (f-06/07/08-01="2")
Data is sent if the WEIGHT display is stable at +5d (weighing display division) and above. The next transmission can not occur until after the weight display falls below +5d.
- £ Auto-print Mode B (f-06/07/08-01="3")
Data is sent if the WEIGHT display is stable at ±5d (weighing display division) and above/below. The next transmission can not occur until after the weight display falls between -5d and +5d.

 To use with the UFC format.
Refer to "12-7. Using UFC (Universal Flex Coms) Function"

Data to be Sent (f-06/07/08-02)

Select which data is to be sent by keying in a **0** or **1** for the data: Date / time, ID Number, PCS (count), weight or unit weight.

Example: Key in **0 1 1 0 0** to display 01100, this setting would send only the ID number and the count.



Data Format (f-06/07/08-03)

- £ Format for AD-8121 MODE 1 or 2. (f-06/07/08-03="0")
- £ Format for AD-8121 MODE 3. (f-06/07/08-03="1")
- £ Format for general apparatuses, computers, etc. (f-06/07/08-03="2")

Baud Rate (f-06/07/08-04)

Select the baud rate according to the device to be connected.

- £ 2400 bps (f-06/07/08-04="0") Select 2400 bps to connect with an AD-8121.
- £ 4800 bps (f-06/07/08-04="1")
- £ 9600 bps (f-06/07/08-04="2")

12-3. Connecting the AD-8121 Printer / MODE 1 or MODE 2

- £ When using the AD-8121 printer (MODE1 or MODE 2), you will be able to get data: Number of data items, total, maximum, minimum, mean value, range of data (max. - min. data) and standard deviation.
- £ When using the AD-8121 with MODE 2, set f-06/07/08-02 to print pcs (count) data only or weight data only.
- £ To print date and time, use the AD-8121's calendar / clock function and set f-06/07/08-2 to print pcs (count) data only or weight data only.

Print Operations Settings

Print By:	F-Function f-06/07/08-01	Printer MODE
FC <input type="button" value="PRINT"/> key	0	MODE 1
Auto Print	2 or 3	MODE 1
Printer <input type="button" value="DATA"/> key	1	MODE 2

Example of f-06/07/08-02 settings


- £ To print pcs (count) data only: set f-06/07/08-02 at "00100"
- £ To print weight data only: set f-06/07/08-02 at "00010"
- £ To print pcs (count) and weight data: set f-06/07/08-02 at "00110"
- £ To print pcs, weight and Unit Weight data: set f-06/07/08-02 at "00111"
- £ To print total data (accumulated by the key), press the key so the Count display shows the total, then press the key.
- £ If you are using the AD-8121's statistic functions, then set f-06/07/08-02 at "001#0" (# = 0 or 1) for pcs (count) data or "00010" for weight data.
- £ MODE 1 and 2 of the AD-8121 can not print ID numbers.

12-4. Connecting the AD-8121 Printer / MODE 3

- £ When using MODE 3 of the AD-8121 printer, printouts are obtained using the **PRINT** key (f-06/07/08-01 = 0), or auto-print mode A/B (f-06/07/08-01 =2 or 3).
- £ MODE 3 can print the ID number with its item code.
- £ To print date/time, set f-06/07/08-02 at "1#####" (# = 0 or 1).
- £ The total data (accumulated by the **M+** key) will be printed along with the number of additions to **M+** memory.

 The AD-8121 / MODE 3 does not have statistical functions.

AD-8121 Printout Sample



12-5. Command Mode

£ In the command mode, the scale is controlled by commands that come from an external device, computer etc.

⚠ Do not set f-06/07/08-01="1" (stream mode) to use with the command mode. if you don't want to use command mode together with key mode or auto-print mode, set f-06/07/08-01="4" (command mode only).

£ Use a D-sub 9 pin cable (straight type) to connect with a computer.
Option cable: AX-KO2466-200, D-sub 9 pin, 2m

Command List

Command	Definition	Notes
@	Start / stop continuous data transmission.	
A	Same as RESET key.	Key command
D	Set a known tare weight.	"D,1.23C _{RL} F" sets the tare weight as "1.23kg".
E	Store the unit weight in use, other values and specified item code to ID memory.	Refer to the data format. Refer f-01-05
F	Recall a unit weight from ID memory.	"F123C _{RL} F" recalls from ID000123.
G	Set a known unit weight.	"G,0.123C _{RL} F" sets the unit weight as "0.123g" (or "0.123 lb").
I	Same as the REMOTE SCALE key.	Key command
J	Same as the TOTAL key.	
K	Same as the M+ key.	Key command
P	Same as the STANDBY/OPERATE key.	
Q	Send data immediately.	Data depends on f-06/07/08-02
S	Send stable data after accepting command.	
T	Same as the TARE key.	Key command
X	Request a list of the F-Function parameters.	The last data terminates with <EOT> (04H)
Y	Request a list of the ID memory contents.	
Z	Same as the ZERO key.	Key command
ON	Turn the display ON.	Refer to the data format for the reply.
OFF	Turn the display OFF.	
?ID	Send the ID number and item code in use.	
?QT	Send the pcs (count) data.	
?WT	Send the weight data.	
?UW	Send the unit weight in use.	
?AQ	Send the total (accumulated) M+ memory count	
?AN	Send the number of additions to M+ memory.	
?TR	Send the tare weight in use.	
?MR	Send the specified ID memory contents.	

Command	Definition	Notes
MR	Store the unit weight and tare weight into the specified ID memory.	Refer to the data format for the reply.
MI	Store the item code into the specified ID memory.	
ML	Store the comparator limits into the specified ID memory.	
MA	Store the total count and number of additions into the specified ID memory.	
CM	Clear the specified ID memory contents	"CM,1.23C _{RL} F" clears content of i d000123.
?FC	Send the specified F-Function setting.	Refer to the data format for the reply.
FC	Store the specified F-Function setting value.	

Acknowledgment and Error Codes

When the scale receives an external command, it reacts as follows:

- £ If the command requests a data reply, the scale will send the data.
For other commands, the scale will send an acknowledgment <AK> (06H) upon acceptance of the command.
- £ If the command is I, S, T or Z, the scale will send a second acknowledgment <AK> (06H) when the command operation is completed.

If an error occurs, the scale will send an error code.

- £ The error format is E C , E n C_R L_F , "n" being the error number.

En	Definition	Notes
E0	Communication error	Parity error, framing error, etc.
E1	Undefined command error	The command does not exist for the scale.
E2	Scale not ready error.	The scale is not in a state where a command could be expected.
E4	Too many characters error	The command contains too many characters.
E6	Format error	The command contains invalid characters.
E7	Out of range error	Value is out of range. The tare weight is more than the capacity, etc.

Data Format

"_" in examples below shows "Space" (20H).

- £ Store the unit weight in use, other values (according to f-01-05) and specified item code

Command

E	,	1	2	3	C	L _F
---	---	---	---	---	---	----------------

 Stores into i d000123 with no item code.

E	,	1	2	3	,	a	b	c	C	L _F
---	---	---	---	---	---	---	---	---	---	----------------

 Stores into i d000123 with item code

Reply

AK

- £ ID number and item code

Command

?	I	D	C	L _F
---	---	---	---	----------------

Reply

I	D	,	0	0	0	1	2	3	C	L _F	A	B	C	D	E	F	G	H	I	J	K	L	C	L _F
---	---	---	---	---	---	---	---	---	---	----------------	---	---	---	---	---	---	---	---	---	---	---	---	---	----------------

} ID number
} Item code (These are "space" for no item code.)

- £ PCS (Count) data

Command

?	Q	T	C	L _F
---	---	---	---	----------------

Reply

Q	T	,	+	0	0	0	0	1	2	3	4	_	P	C	C	L _F
U	S	,	-	0	0	0	0	5	6	7	8	_	P	C	C	L _F
O	L	,	+	9	9	9	9	9	9	9	9	_	P	C	C	L _F

 Stable positive data
 Unstable negative data
 "E" display

- £ Weight data

Command

?	W	T	C	L _F
---	---	---	---	----------------

Reply

S	T	,	+	0	0	1	.	2	3	4	6	_	k	g	C	L _F
S	T	,	-	0	0	2	.	7	2	5	5	_	l	b	C	L _F
U	S	,	-	0	0	1	2	.	3	4	6	_	l	b	C	L _F
U	S	,	+	0	0	0	5	.	5	9	3	_	k	g	C	L _F
O	L	,	+	9	9	9	9	.	9	9	9	_	k	g	C	L _F
O	L	,	-	9	9	9	9	.	9	9	9	_	l	b	C	L _F

 Stable positive data
 Stable negative data
 Unstable negative data
 Unstable positive data
 "E" display
 "-E" display

- £ Unit weight

Command

?	U	W	C	L _F
---	---	---	---	----------------

Reply

U	W	,	+	1	.	2	3	4	5	6	7	_	_	g	C	L _F
U	W	,	+	0	.	2	7	2	5	3	1	_	l	b	C	L _F

- £ Total count

Command

?	A	Q	C	L _F
---	---	---	---	----------------

Reply

A	Q	,	+	0	0	9	9	9	9	9	9	_	P	C	C	L _F
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	----------------

- £ Accumulation number

Command

?	A	N	C	L _F
---	---	---	---	----------------

£ Store the comparator limits into a specified ID memory.

Command

M	L	,	1	2	3	,	+	1	0	1	0	,	+	9	9	0	C	L _F
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	----------------

ID #
Upper Limit
Low Limit

Reply

AK

ID number: Maximum 6 digit
 Upper limit: Maximum 9 digit including sign
 Lower limit: Maximum 9 digit including sign

£ Store the total count and number of additions into a specified ID memory.

Command

M	A	,	1	2	3	,	+	6	7	8	9	,	1	2	3	C	L _F
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	----------------

ID #
Total Count
of Additions

Reply

AK

ID number: Maximum 6 digits
 Total count: Maximum 9 digits including sign
 Number of addition: Maximum 8 digits

£ Request the scale to reply with the F-Function settings.

Command

?	F	C	,	0	5	0	1	C	L _F
---	---	---	---	---	---	---	---	---	----------------

 Request the setting of f-05-01.

Reply

F	C	,	0	5	0	1	,	0	C	L _F
---	---	---	---	---	---	---	---	---	---	----------------

 f-05-01 = 0

F-#
Setting value

Command

?	F	C	C	L _F
---	---	---	---	----------------

 Request to reply with the setting of the next F-Function.

Reply

F	C	,	0	5	0	2	,	0	C	L _F
---	---	---	---	---	---	---	---	---	---	----------------

 f-05-02 = 0

£ Store the specified F-Function setting value

Command

F	C	,	0	5	0	3	,	+	1	2	3	4	C	L _F
---	---	---	---	---	---	---	---	---	---	---	---	---	---	----------------

 Set "1234" as the Upper limit.

F-#
Setting value

F-Function number: 4 digits
 Setting value: Maximum 8 digits including sign.

Reply

AK

Command

O	N	C	L _F
---	---	---	----------------

 Start with new settings.

Reply

AK


⚠ Having finished the "FC" command, send the "ON" command to start the scale with new settings. The scale replies <AK> (06H) and starts.


12-6. Using a Bar Code Reader


- £ The bar code reader can be connected to the RS-232C interface on the scale. It can read bar codes for the ID number, unit weight, tare weight and comparator limits.
- £ Any of the RS-232C interfaces can be used for the bar code reader.
- £ Set the F-Function $f-06/07/08-01="5"$ to use a bar code reader. For example, to use Ch.1 (PORT 1), set $f-07-01="5"$.
- £ Refer to “13-1. OP-01 Bar Code Reader” about the optional bar code reader.


Requirement for the Bar Code Reader


Interface	EIA RS-232C
Baud rate	2400, 4800, 9600 bps
Character code	ASCII
Terminator	C_R or $C_{R\text{LF}}$
Bar code	EAN/JAN, UPC, Codabar (NW-7), Interleaved 2 of 5, Code39 etc., depending on the bar code reader.
Connector	D-Sub 9pin connector (recommended)

 In most cases, a bar code reader with an RS-232C interface is to connect directly with a personal computer. The signals must be converted to connect this kind of bar code reader with the scale. Refer to the diagram below.



 Do not use RS-232C adapter/cable to connect the bar code reader (OP-01) to the RS-232C interface on the scale.

 Some bar codes will have start and stop characters. But, set your bar code reader not to send those characters to the scale. The scale doesn't accept such data.

 EAN/JAN/UPC bar codes usually have a check digit and other bar codes may have either. But, set your bar code reader not to send the check digit. The scale doesn't accept such data. If sent, the scale cannot tell the difference between data and the check digit.

£ Read the instruction/technical manual of your bar code reader to connect it with the scale.

Bar Code Data and Format

£ The bar code data that the scale accepts are ID number, unit weight, tare weight and comparator limits.

£ The bar code has "2 digit identification code + 6 digit numbers" for the ID number and "2 digit identification code + maximum 10 digit numbers including sign and decimal point" for the other data.

£ The unit weight and tare weight must be within 6 digits, except insignificant zeros.

Unit weight 123.456 g:	"12+123.456"	acceptable
	"12+00123.456"	acceptable
	"12+0123.4560"	not acceptable
Tare weight 10 kg:	"15+10"	acceptable
	"15+0000010.0"	acceptable
	"15+010.00000"	not acceptable

£ The comparator limits must be within 7 digits, except insignificant zeros.

Upper limit:	"17+123"	acceptable
	"17+000000123"	acceptable
	"17+012345670"	not acceptable

Bar Code Data	Identification Code	Numbers	Function
ID Number	01	6 digits ID number.	Recall the unit weight by ID number. Similar function to "3-5. Unit Weight By ID Number ".
Unit Weight (g)	12	10 digits including sign and decimal point.	Enter a unit weight in "g" directly. Similar to "3-4. Unit Weight by KEYBOARD ".
Unit Weight (lb)	13	10 digits including sign and decimal point.	Enter a unit weight in "lb" directly. Similar to "3-4. Unit Weight by KEYBOARD ".
Unit Weight (lb/1000pcs)	14	10 digits including sign and decimal point.	Enter a unit weight in "lb/1000pcs" directly. Similar to "3-4. Unit Weight by KEYBOARD ".
Tare Weight (kg)	15	10 digits including sign and decimal point.	Enter a tare weight in "kg" directly. Similar to "4-1. Using the KEYBOARD TARE key ".
Tare Weight (lb)	16	10 digits including sign and decimal point.	Enter a tare weight in "lb" directly. Similar to "4-1. Using the KEYBOARD TARE key ".
Comparator Upper limit	17	10 digits including sign.	Change comparator upper limit temporarily.
Comparator Lower limit	18	10 digits including sign.	Change comparator lower limit temporarily.

Tare Weight (g)	19	10 digits including sign and decimal point.	Enter a tare weight in “g” directly. Similar to “4-1. Using the KEYBOARD TARE key”.
-----------------	----	---------------------------------------------	--------------------------------------------------------------------------------------------

£ If the EAN/JAN/UPC-A is used for ID number, put leading zeros (that are “0” for the high-order digits) to keep the necessary digit number.

Example of ID number “000123”

EAN/JAN-13 01000000123[3] ([3] shows check digit)









EAN-8 0100123[5] ([5] shows check digit)

UPC-A 01000000123[5] ([5] shows check digit)

- ⚠ When the data from bar code reader is not acceptable, the scale will beep 4 times.
- « The data contains too many digits or too many significant digits.
 - « The data contains invalid identification code.
 - « The data is out of range. (The tare data is more than the capacity, etc.)
 - « The tare or unit weight has a minus sign.
 - « The data has start / stop characters or a check digit. These will lead to the invalid identification code, too many digits and so on.

- ⚠ The check digit may be accepted as a wrong number.
Do not set the bar code reader to send the check digit.
Example: EAN-8 / 0100123[5] ([5] is a check digit) can be accepted as ID number “001235”.

Examples of Bar Code

ID Number = 123456	 01123456	Interleaved 2 of 5
ID Number = 123456	 0100001234562	EAN/JAN-13
ID Number = 123	 01001235	EAN/JAN-8
ID Number = 123	 010000001235	UPC-A
Unit weight = 123.456g	 *12+123.456*	Code 39
Unit weight = 0.27217 lb	 *13+000.27217*	Code 39
Tare weight = 1.234 kg	 *15+00001.234*	Code 39
Tare weight = 0.5 lb	 *16+0.5*	Code 39

Comparator upper limit
=12345



Codabar (NW-7)

12-7. Using UFC (Universal Flex Coms) Function

- £ The UFC function allows you to print out as you format the printer (UFC format).
- £ The scale can store the UFC format as text data. It will include parameters to replace with the count data, weight data and so on.
- £ The maximum number of text data is 384 characters.
- £ Using “PF” command, the text data has to be sent to the scale in advance.
When the PRINT key is pressed or by auto-print mode A/B, the scale will send the stored text data with the parameters replaced by the original data.
- £ Terminator for the “PF” command is "C_R" or "C_RL_F".
- £ The UFC format data can be sent through one RS-232C interface only.
Set one of f-06/07/08-01 at "6", "7" or "8" to send the data. The others must be set at "0" ~"5" ("4" will be recommended if the other format data is not necessary to send).

Store Text Data into the Scale Memory

Command	P F , \$ P C , ' T E X T ' , # 2 0 , \$ S P * 2 , &
	\$ C R , \$ L F , \$ W T , \$ C R , \$ L F C L _F
Reply	AK

Terminator

The “PF” command sends text data that will include:

- £ Parameters for the scale data and control codes

Parameter	Data & Code
\$PC	Count
\$WT	Weight
\$UW	Unit weight in use
\$TR	Tare weight in use
\$TL	Total count
\$AN	Accumulation numbers
\$CD	ID number in use
\$NM	Item code in use

Parameter	Data & Code
\$CP	Comparator result
\$DT	Date
\$TM	Time
\$CM	Comma
\$SP	Space
\$CR	Carriage Return
\$LF	Line Feed

These parameters must be used capital letters.

- £ ASCII text string
Text string is described in single quote marks as ‘Data’.
The single quote itself is written as ’’(2 single quotes).
Example: Text ‘ABC’ is described as ’’ABC’’.
- £ The ASCII hexadecimal code
The ASCII hexadecimal codes are written in the form “#” + 2 hexadecimal digits.
This will mainly be used to send control codes that can’t be described as a text string.

Example: #04 "EOT" of ASCII code

£ Repeat data

The control codes \$SP, \$CR and \$LF can be used with "* + maximum 2 digit number". That code will be repeated the number of times designated.

Example: \$LF*9 Repeat "\$LF" 9 times.
\$SP*12 Put 12 "Spaces".

£ Link mark "&"

If you will send more than 2 lines of data, attach "&" to the end of the first line. Then, the scale considers the data to be continued.

⚠ "Space" or ";" will be used to separate these data. You can skip them, but you cannot skip ";" after "PF". You must start with "PF,".

Data Format for the Scale Data

“ ” in examples below shows "Space" (20H).

Parameters for the scale data will be replaced by the format below when the scale sends them out.

⚠ Data has a fixed number of digits including a sign and a decimal point. The insignificant zeros are replaced by "Space (20H)" (except the ID number).

\$PC	+ 1 2 3 4 P C	1234 pcs / 9 digit data + 3 digit unit
\$WT	+ 4 . 3 2 1 0 k g	4.3210 kg / 9 digit data + 3 digit unit
\$UW	+ 1 . 2 3 4 5 6 7 g	1.234567 g / 9 digit data + 3 digit unit
\$TR	+ 1 . 2 3 4 5 k g	1.2345 kg / 9 digit data + 3 digit unit
\$TL	+ 9 9 9 9 9 9 P C	999999 pcs / 9 digit data + 3 digit unit
\$AN	1 2 3 4	1234 times / 8 digit data
\$CD	0 0 0 1 2 3	ID Number 000123 / 6 digit data
\$NM	Z D 5 . 6 V	12 characters
\$CP	O K	Result is "OK" / 2 characters
		Result is not available.
\$DT	0 3 / 1 8 / 2 0 0 3	The order of date obeys f-11-01.
\$TM	1 2 : 3 4 : 5 6	12(h) 34(m) 56(s)

Examples of PF command and AD-8121 Printout Sample

AD-8121 Printout
(f-06/07/08-03=" 0" or "1")


```
= 8` $$$%&'`
DB` N` 8` ) " * J` . . . . .
7ci bh`
. . . . . Ž%&' ( ` D7
I b] h` KY] [ \ h`
. . . . . Ž%" &' ( ) * +` . . [
KY] [ \ h`
. . . . . Ž%" ) &' )` _ [
.
. . . $` #%, #&$$` .
. . . %&. ' ( . ) *` .
.
. . 5/ 8` : 7! ) $$$]`
```

"PF" Command

```
PF, ' ID~', $CD, $CR, $LF, &
' PN~', $NM, $CR, $LF, &
' Count', $CR, $LF, &
$SP*4, $PC, $CR, $LF, &
' Uni t~Wei ght', $CR, $LF, &
$SP*4, $UW, $CR, $LF, &
' Wei ght', $CR, $LF, &
$SP*4, $WT, $CR, $LF, &
$CR, $LF, &
$SP*3, $DT, $CR, $LF, &
$SP*3, $TM, $CR, $LF, &
$CR, $LF, &
' ~-A&D~FC-5000i', $CR, $LF
```

Terminator codes

"~" shows "Space."


 Normally the printer needs to receive the terminator, and do not forget to add the terminator code(s) to the end of text data.

13. OPTIONS



13-1. OP-01 Bar Code Reader

The OP-01 includes a bar code reader, RS-232C cable, AC adapter (100V~240V), power plug adapter (US to European plug) and a setting-up bar code sheet.

- £ The OP-01 bar code reader can be connected to one of the RS-232C interfaces. It can read bar codes for the ID number, unit weight, tare weight and comparator limits.
- £ When the bar code reader reads the ID number, the scale will recall unit weight from ID memory instead of by using the **ID** key.
- £ Set the F-Function f-06/07/08-01="5" to use a bar code reader. For example, to use Ch.1 (PORT 1), set f-07-01="5".


 Refer to "12-6. Using a Bar Code Reader" about the bar code data and prepare bar code labels.

- £ The OP-01 bar code reader can be connected to one of the RS-232C interfaces. It can read bar codes for the ID number, unit weight, tare weight and comparator limits.



Using OP-01 Bar Code Reader








1. Plug the modular connector of RS-232C cable into the port on the bottom of bar code reader, and twist the lock to the right to lock it.
2. Connect the other end of the RS-232C cable to the RS-232C interface of the scale.
3. Plug in the AC adapter for OP-01. AC adapter jack is located at the side of the RS-232C cable connector.
4. Set the F-Function $f-06/07/08-01="5"$ according to the interface you connected. For example, to use Ch.1 (PORT 1), set $f-07-01="5"$.
5. Read the next bar codes step by step, then the bar code reader will be set to work with the scale.



- ⚠ This sets the RS-232C to be 9600 bps and 8 bits data / non parity. Set the F-Function $f-06/07/08-04="2"$ and $f-06/07/08-05="2"$. For example, to use Ch.1 (PORT 1), set $f-07-04="2"$ and $f-07-05="2"$.
- ⚠ By this set-up, the FC-*i* / FC-*Si* can accept bar codes of EAN-13/8, JAN-13/8, UPC-A/E, Codabar (NW-7), Interleaved 2 of 5 and Code 39.
- ⚠ The UPC-A bar code can not be used together with EAN/JAN-13. Refer to "Note 1" at "Step 4".

Note 1: When using UPC-A bar code, skip "Step 4".

STEP	Set-up Bar Code	Definition
Step 1		Start of configuration
Step 2		Rest to default settings
Step 3		Select RS-232C interface
Step 4 Refer to Note 1		Force UPC-A to EAN-13
Step 5		Disable transmitting UPC-A check digit



Step 6		Disable transmitting UPC-E check digit
Step 7		Disable transmitting EAN-13 check digit
Step 8		Disable transmitting EAN-8 check digit
Step 9		Disable transmitting CODABAR Start/Stop character
Step 10		Disable transmitting CODE 39 check digit
Step 11		Disable transmitting Interleaved 2 of 5 check digit
Step 12		End of configuration

13-2. OP-02 Ni-MH Battery Pack



Using OP-02 Battery Pack

£ By using the OP-02 Ni-MH battery pack, the scale can be operated for around 10 hours, after a full charge and using no other options.

1. After making sure that the battery switch on the battery pack is "OFF" position, insert the battery pack firmly into the rear side of the scale.



2. Tighten the lock screw on the battery pack.
3. When desired, turn the battery switch on to supply power to the scale. The display will come on after its self-check.
4. Use the **STANDBY/OPERATE** key to turn the display on or off. When the scale is in standby mode, a period appears in the weight display as an indicator.



⚠ When the count display shows "lo bat" for low battery, the battery power is almost exhausted and should be recharged.

⚠ Before getting to low battery, the display will show "lo bat" on and off to indicate that the battery power is coming close to low battery.

lo bat



The **STANDBY/OPERATE** key only turns the display on or off (and keeps the scale warmed up on standby). When the scale is not used for a long periods, switch the battery switch to "OFF" position.

Recharging the Battery

1. Turn the battery switch off on the battery pack.

2. Fully loosen the lock screw and remove the battery.

£ If you want to recharge the battery while it is still in the scale, you may do so. In that case, disregard step 2 – but do not turn the battery switch on. If you wish to use the scale, connect another AC adapter.

3. Connect the AC adapter to the battery pack.

£ The battery pack will take about 15 hours to fully charge.

£ Charge the battery pack at a temperature between 0°C (32°F) and 40°C (104°F).

£ Do not charge too long as overcharging will reduce the life of batteries.

£ Be sure to charge the battery pack when using for the first time or if it was not used for long time (more than one month). Two or three times of recharging may be needed to reach full charge.

£ Be sure to use the AC adapter that is provided with the scale.

Battery switch	AC Adapter to battery pack	AC Adapter to scale	Charge	Scale operation
ON or OFF	Connected	Connected	Yes	Operational
ON or OFF	Not connected	Connected	No	Operational
OFF	Connected	Not connected	Yes	Not operational
ON	Connected	Not connected	No	Not recommended (See note)

Note The scale will be operational. After connecting the AC adapter to the battery pack, you may have to turn the battery switch OFF once and turn it ON to operate the scale.


13-3. OP-03 2 Ch. RS-232C

Multiple RS-232C interfaces expanding your counting applications are obtained by installing OP-03.

OP-03 Installation

1. Disconnect the AC adapter from the scale.
2. Remove the two screws and panel covering the OP-03/04 slot.
3. Connect the connector in the scale to the OP-03 unit.
4. Secure the OP-03 unit using the screws removed in the step 2 above.

£ Specifications are same as the standard RS-232C interface and refer to “12. RS-232C SERIAL INTERFACE”.




13-4. OP-04 RS-232C and Comparator Relay Output


Multiple RS-232C interfaces and relay output for the comparator results are obtained by installing OP-04.

OP-04 Installation

- £ See the OP-03 installation.
- £ OP-04 is installed to the same slot as option OP-03.
- £ The RS-232C specifications are same as the standard RS-232C interface. Refer to “12. RS-232C SERIAL INTERFACE”.



Comparator Relay Output Circuit



Maximum rating of the Relay Output

The maximum rating of the replay output is as follows.



- £ Maximum voltage: 50V DC
- £ Maximum current: 100mA DC
- £ Maximum ON resistance: 8T

13-5. OP-05 Remote Scale Interface

A two-scale system using the scale is possible by installing OP-05 and connecting a remote scale. You can use any load cell platform that meets the conditions in this section.

OP-05 Installation

1. Disconnect the AC adapter from the scale.
 2. Remove the two screws and panel covering the Remote scale slot.
 3. Connect the connector in the scale to the OP-05 unit.
 4. Secure the OP-05 unit using the screws removed in the step 2 above.
- £ If you are not using the remote scale for the moment, attach the protective screw cap to the remote scale connector.



Notes on Using the Remote Scale

- £ To get a highly accurate counting unit weight, use the main scale to register the unit weight and use ACAI feature. After registration, switch to the remote scale to count.
- £ If f-01-03 is set at "1", then the scale will automatically switch to the remote scale after the unit weight (by sample pieces) is registered by the main scale. Pressing the **SAMPLE** key will always return to the main scale.
- £ Be aware that both the main and remote scales have separate tare values. So, if you want to use a tare container on both, it must be tared on both.
- £ F-Function f-01-06 can be set so the remote scale has an independent unit weight, or is restricted to the same as the main scale.

Specifications for Remote Scale

The scale has the ability of driving up to 4 load cells (350T) in a remote scale (platform). Set for the capacity range 0.5kg to 5,000kg (1 lb to 10,000 lb).

£ The scale has the ability of driving up to 4 load cells (350T) in a remote scale (platform).

£ **Capacity range** for the remote scale is 0.5kg to 5,000kg (1 lb to 10,000 lb).

£ **Minimum output** at zero point is 1mV.

£ **Maximum output** at full load is 14mV.

 Excitation Voltage of the scale is 5V.

£ **Cable length** should be kept under 5m (16.5 ft.) for higher accuracy.

£ **Pin connection** (JM:NJC-207-PF):

The Load Cell and Input Sensitivity

The relationship between load cell and input sensitivity (X) for the scale is follows:

£ Example	Load Cell Capacity	100kg	"A"
	Rated Output	3mV/V	"B"
	Min., Division of Display	0.01kg	"D"

£ When a single Load Cell is used, the following formula should apply:

$$"X" = \frac{5,000 \times B \times D}{A} \mu V$$

£ System design will be satisfactory if "X" is greater than 0.5µV. In the example above

$$"X" = 1.5 \mu V.$$

Capacity and Resolution

£ The resolution of the remote scale is automatically determined during the calibration procedure. The following is to enable you to calculate the resolution for a given capacity.

1. Decide the capacity value and assign it to "Ws". Maximum 5 digits.
2. Get the maximum count "Ns" for the capacity. Ignore the decimal point and add "0" to Ws until it is 5 digits.
3. Calculate: $d' = Ns / 10,000$.
4. Decide the minimum division "d".

$d' = 1$	à	$d = 1$
$2 \leq d' < 10$	à	$d = 2$
$5 \leq d' < 10$	à	$d = 5$
$d' > 10$	à	$d = 10$

This should be changed to $d = 1$, dividing Ns by 10.
5. Now "Ns x d" and the resolution $1/No = d/Ns$ can be determined.

Step	Parameters	Example 1	Example 2	Example 3
1	Ws	200kg	30.0kg	600kg
2	Ns	20,000	30,000	60,000
3	d'	2	3	6
4	d	2 (=0.02kg)	5 (=0.005kg)	10 (=0.1kg)
5	Ns x d	20,000 x 2	30,000 x 5	6,000 x 1
	1/No (=d/Ns)	1/10,000	1/6,000	1/6,000

6. Calculate the voltage sensitivity "Es".

$$Es = (As - Ao) \times 5,000 \times 1/No \text{ (}\mu\text{V)} \quad [5,000 \text{ means excitation voltage } 5\text{V}]$$

Ao: Load cell output at zero point (mV/V)

As: Load cell output at full capacity (mV/V)

7. Check the voltage sensitivity "Es".

$Es \geq 0.5\mu\text{V}$ à Calculated "Ns x d" is fixed. In example 3 in the step 5, a 600kg x 0.1kg scale will be obtained.

$Es < 0.5\mu\text{V}$ à Change "d" for new resolution 1/No.

$$d=1 \text{ à } 2$$

$$d=2 \text{ à } 5$$

$$d=5 \text{ à } 10 \text{ à } 1 \text{ (dividing "Ns" by } 10)$$

In example 1,

$$\text{the new } d=5: 1/No = d/Ns = 5/20,000 = 1/4,000 \text{ (200kg x } 0.05\text{kg)}$$

In example 2,

$$\text{the new } d=1 \text{ and } Ns=3,000: 1/No = d/Ns = 1/3,000 \text{ (30kg x } 0.01\text{kg)}$$

Using the new 1/No, go to step 6 and repeat it until $Es \geq 0.5\mu\text{V}$ in step 7.

Remote Scale kg/lb relationship

USA Version ONLY

£ When the capacity was set by "kg":

$$\text{Let capacity x minimum division} = Ws \times Wd \text{ (kg)}$$

When:

$$d = 1, \text{ then } Wd \text{ (lb)} = Wd \text{ (kg)} \times 2$$

$$d = 2, \text{ then } Wd \text{ (lb)} = Wd \text{ (kg)} \times 5/2$$

$$d = 5, \text{ then } Wd \text{ (lb)} = Wd \text{ (kg)} \times 2$$

And:

$$Ws \text{ (lb)} = Wd \text{ (kg)} \times No$$

$$\text{Example: } 15\text{kg} \times 0.002\text{kg}, No = 15\text{kg}/0.002\text{kg} = 7,500$$

$$Wd \text{ (lb)} = 0.002 \times 5/2 = 0.005 \text{ (lb)}$$

$$Ws \text{ (lb)} = 0.005 \text{ (lb)} \times 7,500 = 37.5 \text{ (lb)}$$

£ When the capacity was set by "lb":

$$\text{Let capacity x minimum division} = Ws \times Wd \text{ (lb)}$$

When:

$$d = 1, \text{ then } Wd \text{ (kg)} = Wd \text{ (lb)} \times 1/2$$

$$d = 2, \text{ then } Wd \text{ (kg)} = Wd \text{ (lb)} \times 1/2$$

$$d = 5, \text{ then } Wd \text{ (kg)} = Wd \text{ (lb)} \times 2/5$$

And:

$$Ws \text{ (kg)} = Wd \text{ (lb)} \times No$$

$$\text{Example: } 30\text{lb} \times 0.005\text{lb}, No = 30\text{lb}/0.005\text{lb} = 6,000$$

$$W_d \text{ (kg)} = 0.005 \times 2/5 = 0.002 \text{ (kg)}$$

$$W_s \text{ (kg)} = 0.002 \text{ (kg)} \times 6,000 = 12 \text{ (kg)}$$


Calibrating the Remote Scale

⚠ When a remote scale is newly connected, set the capacity and calibrate the scale using a weight.

⚠ The scale must be warmed up (plugged in) for at least 30 minutes before starting calibration.

1. Remove the calibration switch cover, and press the calibration **CAL** switch. The scale shows "CAL" in the count display.


£ Press the **CAL** switch to exit without calibrating the scale.




2. Press the **REMOTE SCALE** key to display SCALE "&".

⚠ When SCALE "%" is displayed, press the **REMOTE SCALE** key again.

£ Once the remote scale has been calibrated, the display will go to step 4.





3. Use the **0** à **9** and **.** 10-key pad to display the desired capacity. (Example of capacity 2000kg)





4. Press the **ENTER** key. The capacity value stops blinking.

£ When the remote scale has been changed or to change capacity, go back to step 3.



5. Press the **ENTER** key again to store the capacity entered and the remote scale is ready to be calibrated.



6. Go to step 2 in section “9-1. Calibration Procedure Using a Weight” to calibrate the remote scale.

14. SPECIFICATIONS

MODEL	FC-500i	FC-1000i	FC-2000i	FC-5000i	FC-10Ki	FC-20Ki	FC-50Ki
Capacity (k)g	500 g	1 kg	2 kg	5000 g	10 kg	20 kg	50 kg
Resolution (k)g	0.05 g	0.1 g	0.2 g	0.5 g	1 g	2 g	5 g
Capacity lb	1 lb	2 lb	5 lb	10 lb	20 lb	50 lb	100 lb
Resolution lb	0.0001 lb	0.0002 lb	0.0005 lb	0.001 lb	0.002 lb	0.005 lb	0.01 lb
Sample Size	10 pieces normal – 5, 25, 50, 100 or random number, user selectable						
Min. Unit Weight (Normal mode)	0.01 g	0.02 g	0.04 g	0.1 g	0.2 g	0.4 g	1 g
Min. Unit Weight (Fine mode)	0.0005 g	0.001 g	0.002 g	0.005 g	0.01 g	0.02 g	0.05 g
Non-linearity	±0.05 g	±0.1 g	±0.2 g	±0.5 g	±1 g	±2 g	±5 g
Repeatability	0.05 g	0.1 g	0.2 g	0.5 g	1 g	2 g	5 g
Span Drift	0.002%/°C (5°C~35°C) typ.						
Operating Temp.	-10°C to 40°C/14°F to 104°F, less than 85%R.H. (No Condensation)						
Display	7 segment / 5x7 dot VFD						
Display Update	Approximately 10 times per second						
Interface	RS-232C (1ch.) standard, Maximum 3 ch. with optional interface						
Power	AC adapter or Optional Ni-MH Battery Pack Battery Operating Time: Approx. 10 hours (main scale only)						
Platform Size	205 x 152 (mm) 8.1 x 6.0 (inches)		315 x 270 (mm) 12.4 x 10.6 (inches)				
Dimensions (W) x (D) x (H)	330 x 462 x 107 mm 13.0 x 18.2 x 4.2 inches		330 x 462 x 117 mm 13.0 x 18.2 x 4.6 inches				
Weight (approx.)	5.5 kg	5.5 kg	6.5 kg	6.7 kg	6.7 kg	6.7 kg	7.5 kg
Calibration Weight	500 g ± 0.01 g	1 kg ± 0.02 g	2 kg ± 0.05 g	5kg±0.1g	10kg±0.2g	20kg±0.5g	50kg±1g
Accessories	This manual, AC adapter						







MODEL	FC-500Si	FC-5000Si
Capacity g	500 g	5000 g
Resolution g	0.02 g	0.2 g
Capacity lb	1 lb	10 lb
Resolution lb	0.00005 lb	0.0005 lb
Sample Size	10 pieces normal – 5, 25, 50, 100 or random number, user selectable	
Min. Unit Weight (Normal mode)	0.001 g	0.01 g
Min. Unit Weight (Fine mode)	0.00005 g	0.0005 g
Non-linearity	±0.02 g	±0.2 g
Repeatability	0.02 g	0.2 g
Span Drift	0.001%/°C (5°C~35°C) typ.	
Operating Temp.	5°C to 40°C/41°F to 104°F, less than 85%R.H. (No Condensation)	
Display	7 segment / 5x7 dot VFD	
Display Update	Approximately 10 times per second	
Interface	RS-232C (1ch.) standard, Maximum 3 ch. with optional interface	
Power	AC adapter or Optional Ni-MH Battery Pack Battery Operating Time: Approx. 10 hours (main scale only)	
Platform Size	128 x 128 (mm) / 5.0 x 5.0 inches	165 x 165 (mm) / 6.5 x 6.5 inches
Dimensions (W) x (D) x (H)	330 x 462 x 106 mm 13.0 x 18.2 x 4.2 inches	
Weight (approx.)	7.6 kg	8.1 kg
Calibration Weight	500 g ± 0.005 g	5000 g ± 0.05 g
Accessories	This manual, AC adapter	

Options



- OP-01 Bar Code Reader
- OP-02 Ni-MH Battery Pack
- OP-03 RS-232C x 2ch. (Confirm the following note)
- OP-04 RS-232C x 1ch. + Comparator Relay output (Confirm the following note)
- OP-05 Remote Scale Interface
- Note OP-03 and OP-04 can not be installed at the same time.

14-1. Dimensions





FC-2000i
 FC-5000i
 FC-10Ki
 FC-20Ki
 FC-50Ki



FC-500i
 FC-1000i



FC-5000Si




FC-500Si


15. GRAVITY ACCELERATION MAP

Values of gravity at various locations

Amsterdam	9.813 m/s ²	Manila	9.784 m/s ²
Athens	9.807 m/s ²	Melbourne	9.800 m/s ²
Auckland, NZ	9.799 m/s ²	Mexico City	9.779 m/s ²
Bangkok	9.783 m/s ²	Milan	9.806 m/s ²
Birmingham	9.813 m/s ²	New York	9.802 m/s ²
Brussels	9.811 m/s ²	Oslo	9.819 m/s ²
Buenos Aires	9.797 m/s ²	Ottawa	9.806 m/s ²
Calcutta	9.788 m/s ²	Paris	9.809 m/s ²
Cape Town	9.796 m/s ²	Rio de Janeiro	9.788 m/s ²
Chicago	9.803 m/s ²	Rome	9.803 m/s ²
Copenhagen	9.815 m/s ²	San Francisco	9.800 m/s ²
Cyprus	9.797 m/s ²	Singapore	9.781 m/s ²
Djakarta	9.781 m/s ²	Stockholm	9.818 m/s ²
Frankfurt	9.810 m/s ²	Sydney	9.797 m/s ²
Glasgow	9.816 m/s ²	Taichung	9.789 m/s ²
Havana	9.788 m/s ²	Taiwan	9.788 m/s ²
Helsinki	9.819 m/s ²	Taipei	9.790 m/s ²
Kuwait	9.793 m/s ²	Tokyo	9.798 m/s ²
Lisbon	9.801 m/s ²	Vancouver, BC	9.809 m/s ²
London (Greenwich)	9.812 m/s ²	Washington, DC	9.801 m/s ²
Los Angeles	9.796 m/s ²	Wellington, NZ	9.803 m/s ²
Madrid	9.800 m/s ²	Zurich	9.807 m/s ²



World map



16. INDEX

-----	10, 11, 13, 14, 15
* key	9, 27, 29, 42
~ , Space code	52, 59, 60
• , Standby indicator	7
AC adapter	4, 5, 6
AC adapter jack	5
ACAI	38, 44, 45
ACAI indicator	9
Accessories	72, 73
AD-8121	41, 48, 49
Add	36
Add Sample	13, 14, 15, 16
Alphanumeric character table	24
Bar code	
Bar code reader	55, 61
Check digit	57, 62
Codabar (NW-7)	57, 62
Code 39	57, 62
EAN/JAN-13	57, 62
EAN/JAN-8	57, 62
Identification code	56
Interleaved 2 of 5	57, 62
PF command	58
UFC (Universal Flex Coms)	58
UPC-A	57, 62
Battery	64
Baud rate	41, 46, 48
Best conditions	5
C key	9
Cal	31
Cal 0	32
Cal f	32
Calibration	31, 71
Calibration End	32
Calibration switch	5, 31
Calibration weight	32, 72, 73
Capacity	72, 73
Capital letter	23, 24
Comparator function	28
Comparator limit	25
Comparator result	40
Lower limit	28, 29, 40
Upper limit	28, 29, 40
Count data	26
Counting	12
Data format	41, 46, 48, 52
Data length	41
Date and time	47
Dimensions	72, 73
Display off	5
Earth terminal	5
ENTER key	9
err 1	10
Error code	51
f-00	34
F-Function	34
Gravity acceleration	32, 33, 75
HI	28, 40
Humidity	6
id	8, 18
id-----	22
ID key	9, 25
ID number	
.....	8, 9, 12, 18, 21, 22, 23, 25, 47, 61
id-all	22
Interface	46, 66, 67, 68
Item code	21, 23, 25
KEYBOARD TARE key	9
LO	28, 40
lo bat	64
lo ut	16, 17
Load cell	68, 69, 71
Lowercase letter	23, 24
M- key	9, 27, 42
M+ (A/a) key	23, 24
M+ indicator	9, 26
M+ key	9, 26
Memory function	26, 37, 38
Minimum unit weight	38
Mode	
Auto-print mode A	47
Auto-print mode B	47
Calibration	31
Command mode	50
Comparator mode	39
Data output mode	40, 47
Key mode	47
Normal operation	36

Operating mode	7, 36	Stable detection speed	39
Simple operation	36	STABLE indicator	9
Simple operation mode	7	Standby indicator	7, 10
Standby mode	7	STANDBY/OPERATE key	5, 7, 9, 64
Stream mode	47	Start bit	46
Net weight	19	Stop bit	46
no i d	18	STORE UNIT WEIGHT key	9, 21, 22, 23, 24
Numerical keys	9, 23, 24	TARE ENTERED indicator	9, 11, 19
OK	28, 40	TARE key	9, 11, 19
OP-01	61	Tare operation	19
OP-02	64	Tare weight	25
OP-03	66	Terminator	46
OP-04	67	Time and date	30, 43
OP-05	68	Total count	25, 27
Operating mode	36	TOTAL indicator	9, 27
Operating temperature	6, 72, 73	TOTAL key	9, 24, 26, 27
Parity	41, 46	Total weight	13
pCS	13, 14, 15, 16, 44, 45, 47	Unit	7, 8
Power	72, 73	kg	7, 36
PRINT key	9, 24	Kilogram	7, 36
Printer	48, 49	lb	7, 36
Remote scale	5, 36, 37, 44, 68, 69, 70	Pounds	7, 36
REMOTE SCALE key	9	Weighting unit	7, 36
RESET key	9, 12	Unit weight	8, 12, 13, 14, 15, 16, 17, 18, 21, 22, 25, 37, 44, 45, 47, 72, 73
Resolution	72, 73	Minimum unit weight	38
RS-232C	5, 46, 55, 61, 66, 67	UW(g)	8, 9, 13, 14, 18, 21, 44, 45
SAMPLE key	9, 13, 14, 15, 16, 17	UW(l b)	7
Sample size	13, 14, 15, 16, 17, 72, 73	Warm up	5, 6, 31
SAMPLE TOO LIGHT indicator	9	Weighing pan	5
Second	30	Weight	72, 73
Self-check	5	Zero calibration	32
Signal input	42	ZERO indicator	9, 10
Slot		ZERO key	9, 10
OP-02	5, 64	Zero tracking	10, 39
OP-03/04	5, 66		
Remote scale	68		
Span calibration	32		
Spirit level	5		

* key

~ , Space code

• , Standby indicator



A&D Company, Limited

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013 JAPAN
Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-6148

A&D ENGINEERING, INC.

1555, McCandless Drive, Milpitas, CA. 95035 U.S.A.
Telephone: [1] (408) 263-5333 Fax: [1] (408)263-0119

A&D INSTRUMENTS LTD.

Unit 24/26 Blacklands Way, Abingdon Business Park, Abingdon, Oxon OX14 1DY United Kingdom
Telephone: [44] (1235) 550420 Fax: [44] (1235) 550485

<German Scales Office>

Große Straße 13 b 22926 Ahrensburg GERMANY
Telephone: [49] (0) 4102 459230 Fax:[49] (0) 4102 459231

A&D MERCURY PTY. LTD.

32 Dew Street, Thebarton, South Australia 5031 AUSTRALIA
Telephone: [61] (8) 8352-3033 Fax: [61] (8) 8352-7409

A&D KOREA Limited

8th Floor, Manhattan Bldg. 36-2 Yoido-dong, Youngdeungpo-ku, Seoul, KOREA
Telephone: [82] (2) 780-4101 Fax: [82] (2) 782-4280